




# Chelveston Village Hall

## Dishwasher Instructions

The dishwasher needs to be switched on and filled with water 20 minutes before you want to start the first wash. This allows the two tanks (wash and rinse) to heat up to the correct temperature.



1. Switch the machine on at the wall and using the “On/Off” button
2. Press the “Fill/Wash” button to fill the tanks with water
3. Wait until the tanks have both reached temperature. Each of the heater lights will come on in turn and then go off once that tank has reached temperature. This usually takes 15-20 minutes. The lights will then come on intermittently as the heaters maintain the temperature of the tanks. You can start the first wash as soon as the second light has gone out for the first time.
4. Empty glasses into the sink before loading into the dishwasher.
5. Ensure that surplus food is scraped from crockery and cooking pans before loading into the dishwasher. A quick rinse of crockery and pans under the tap before loading into the dishwasher will also improve performance.
6. Select the “cycle length” 1 = Glassware, 2=Crockery and cutlery, 3=Pots and pans.
7. Don’t overload the dishwasher. It is so quick that you can do the next wash in a few minutes.
8. Press the “Fill/Wash” button to start the wash. The machine will “beep” when it is finished.
9. Unload the dishwasher and put in the next load. Press “Fill/Wash” to restart it.
10. At the end of the last load press and hold the “Drain down” button for 3-4 seconds. The dishwasher will then pump all water out.
11. When the pump stops working, switch off the machine and the wall switch.
12. Wipe down the inside of the machine. Put the trays back in and leave the door open to allow the machine to dry.
13. If the “Regenerate softener” light comes on, then you’ll need to press and hold that button for 3-4 seconds so that the regenerate cycle can run. This will need to be done before the next wash.